




IMPORTANT INFORMATION



IMPORTANT: Disconnect before High Voltage Insulation testing




=




Infinitas Continuous System

- This Document and the Tool Kit must be left on site with the end user
- Disconnect electricity supply before installation
- To be installed by qualified personnel only
- The Infinitas Wiring Harness is rated at 16A, therefore several mains/dimming supplies may be required for larger systems
- Before installing please familiarise yourself with the orientation of the Modules male/female wiring connections to ensure correct continuity is achieved
- Infinitas Corners can be either left or right handed. Fit the Plug/Harnesses to each Connector Block to maintain a Male/Female connection to the adjoining Module. Ensure the cables are inserted into the correct terminals by matching the cable colours to the Connector Block label to ensure correct polarity.
- When installing, Hacer recommends wearing disposable gloves to avoid fingerprinting to the paint work of the luminaire


All Modules




To remove Infinitas Manta Fascias, undo the 3x screws securing the Fascia and then disconnect the plug/socket arrangements.



Temporarily mark matching Diffusers, Gear Trays and Housings




End Cap




Where applicable
Plug's supplied with Surface and Pendant versions only


Fixing Centres (mm)




1




2




3




Fixing Centres (mm)




1




2



Clamping Centres (mm)




1



Maximum clamping thickness 35mm


Cut out size: Width 102mm x Total Length of all Modules + 40mm (for End Caps if applicable) + 10mm (clearance)
For Emergency Modules the Indicator must be fitted into the Remote Holder, which requires a 20mm diameter cut out adjacent to the Emergency Module.

2




Note screw position

3




4




Maximum clamping thickness 35mm

Tip: Adjust to slightly higher than the thickness of the mounting surface


5




6



1




2



Surface and Recessed Modules use 100mm Slide Plates,
Suspended Modules use 555mm Slide Plates
(560mm Suspended Modules use 100mm Slide Plates).


3



4


Infinitas Corners can be either left or right handed. Fit the Plug/Harnesses to each Connector Block to maintain a Male/Female connection to the adjoining Module. Ensure the cables are inserted into the correct terminals by matching the cable colours to the Connector Block label to ensure correct polarity.

For Direct Indirect Corner Modules, the Suspension Clutch Plates and the Green Plugs may need to be swapped around to ensure mechanical continuity.



For Modules where mains/dimming supply is to be fed, remove Male plugs, if applicable.

5




See Wiring Information section

6


For Direct Indirect Modules make connection.
Ensure correct polarity is observed.

For Emergency versions, battery connections should only
be made when a permanent mains supply is in place.

For Suspended/Surface versions the Emergency Indicator
should be fitted into the pre-drilled hole in the Module.
For recessed versions the Emergency Indicator should be
fitted into the Indicator Holder which should be fitted into
the ceiling adjacent to the Module.





7




8

Ensure end of reflectors are aligned with
end of Modules. Do not tighten screws
until you are certain that the Geartrays
are correctly aligned.




9





For Direct Indirect Modules make connection. Ensure correct polarity is observed.

10








11




Reconnect the mains supply to ensure all Modules are illuminated correctly.

12



13



Maintenance

- Disconnect electricity supply before carrying out maintenance, including cleaning Diffusers.
- Maintenance must be carried out by two persons.
- When removing Modules and Geartrays ensure that they are lowered parallel to the mounting surface.
- When replacing Suspended Modules the Suspension Wires must also be replaced.

Removing Geartrays (2 persons)

- Remove the Diffuser/Fascia as shown on page 1.
- Remove the Geartray fixing screws ensuring that both ends of the Geartray are supported during the procedure.
- The Geartray will then drop free of the Module allowing the electrical connections to be disconnected.



Wiring Information

		Non Dim/Emergency	DALI Dim/Emergency	Switch Dim/Emergency	PIR/PIR DALI/Emergency
Black	L2	Unswitched Live (Emergency)	Unswitched Live (Emergency)	Unswitched Live (Emergency)	Unswitched Live (Emergency)
Brown	L1	Switched Live	Unswitched Live	Unswitched Live	Not used
Green/Yellow	PE	Earth	Earth	Earth	Earth
Blue	N	Neutral	Neutral	Neutral	Neutral
Orange	L3	Not used	Not used	Not used	Unswitched PIR Live
Red		Not used	DALI 1	Switched Live (DIM)	Not used
White		Not used	DALI 2	Not used	Not used



HACEL LIGHTING LTD.

THE SILVERLINK
WALLSEND
NEWCASTLE UPON TYNE
TYNE & WEAR
NE28 9ND
UK

For further Technical information

Tel: 0191 280 9911

Then choose the following number :

Technical Dial: 4

technical@hacel.co.uk

www.hacel.co.uk