

IMPORTANT INFORMATION



Emy 245



Emy 246

Emy 245/246 Emergency Downlighter

1. **NB:** Ensure electrical supply is isolated before fitting and/or making any electrical connections. Luminaires should be disconnected from the mains supply before any High Voltage Insulation tests are carried out.
2. Cut a 98mm diameter hole in the mounting surface.
3. Bring the mains/DALI (if applicable) cabling through the cutout.
4. Remove the lid from the gearbox.
5. Make the mains/DALI (if applicable) connections to the connector block/s according to the information on the label adjacent to the connector block/s. The Live must be a permanent supply.
6. **NB:** Ensure battery connection is made before replacing the lid.
7. Refit the connector block box lid.
8. Lift the legs of the fixing springs and locate into the cutout.
9. Centre the luminaire to ensure none of the cutout is visible.
10. Reconnect the electrical supply and test the installation.