

## IMPORTANT INFORMATION

### iMod® Inset Grid IM1197



1. *Ensure electrical supply is isolated before fitting and/or making any electrical connections. Luminaires should be disconnected from the mains supply before any High Voltage Insulation tests are carried out.*
2. Remove the ceiling tile in required position.
3. A minimum clearance of approximately 200mm is required above the ceiling for installation.
4. Feed the Mains/Dimming cable through the aperture.
5. Make the Mains/Dimming connections to the Driver according to the information on the Driver or on the label of Emergency versions.
6. For Emergency versions the battery connection should be made only when a permanent mains supply is in place.
7. Angle the luminaire through the aperture and drop it down so that the panel is sitting securely on the T-Bars.
8. Alternatively wiring can be carried out by removing an adjacent tile after the Panel has been fitted.
9. Reconnect the electrical supply and test the installation.