IMPORTANT INFORMATION

Avara Grid IM1181/IM1183/IM1199



Avara 6 Grid Light Shown

- **NB:** Ensure electrical supply is isolated before fitting and/or making any electrical connections. Luminaires should be disconnected from the mains supply before any High Voltage Insulation tests are carried out.
- 2. Remove the ceiling tile in required position.
- 3. A minimum clearance of approximately 200mm is required above the ceiling for installation and ventilation purposes.
- 4. Feed the Mains/Dimming cable through the aperture.
- 5. Make the Mains/Dimming connections to the Driver according to the information on the Driver or on the label of Emergency versions.
- 6. For Emergency versions the battery connection should be made only when a permanent mains supply is in place.
- 7. Angle the luminaire through the aperture and drop it down so that the panel is sitting securely on the T-Bars.
- 8. Alternatively wiring can be carried out by removing an adjacent tile after the Panel has been fitted.
- 9. Reconnect the electrical supply and test the installation.

