

IMPORTANT INFORMATION

Flite® Wallwasher (TT/TD1208)



Three Circuit and DALI Track (read in conjunction with track installation document)

1. *Ensure electrical supply is isolated before fitting and/or making any electrical connections. Luminaires should be disconnected from the mains supply before any High Voltage Insulation tests are carried out.*
2. Turn the lever at one end of the Track Adapter (or both ends with DALI Track) so that the electrical connections are withdrawn into the Track Adapter.
3. The circuit selector dial can be operated either before or after the luminaire is fitted into the track.
4. Rotate the dial to select O (off), 1, 2 or 3 by aligning the number with the mark on the face of the Track Adapter depending on the circuit required for that luminaire.
5. Offer the luminaire up to the Track at a slight angle so that the dial is slightly lower than the opposite end of the Track Adapter.
6. Insert the luminaire into the Track ensuring that the Track Adapter is properly located.
7. The Track Adapter will only fit into the track in one orientation to ensure correct polarity. Do not force the Track Adapter into the Track, if it proves difficult to insert, try the other orientation.
8. Turn lever/s back to engage the electrical connections.
9. If the circuit selector dial was set at O, rotate it to select 1, 2 or 3 depending on the circuit required for that luminaire.
10. Reconnect the electrical supply and test the installation.

Bluetooth variants: Repeater Units maybe required depending on mounting location or site conditions (contact Technical for advice).