

IMPORTANT INFORMATION

Soledo® Pendant PN244



1. **NB: Ensure electrical supply is isolated before fitting and/or making any electrical connections. Luminaires should be disconnected from the mains supply before any High Voltage Insulation tests are carried out.**
2. **NB: For emergency versions you must make the battery bullet connection. To do this, remove the single locking screw below the top plate of the luminaire. You will now be able to twist the luminaire clockwise to separate it from the top plate.**
Now reach into the luminaire and make the battery bullet connection.
Reverse the steps to re-install the luminaire onto the top plate, make sure to hand tighten the locking screw.
NB: Do not overtighten the locking screw
3. Make provision for fixing holes with centres of 50mm.
4. Make an access hole for the mains/dimming cabling in the centre of the fixing holes.
5. Bring the mains/dimming cabling (from the void) through the access hole.
6. Unscrew the Cable Gland to separate the Mounting Plate from the Mounting Plate Cover and disconnect the Earth Cable from the Earth Tab.
7. Insert each of the three Suspension Wires through the 2.5mm diameter holes in the Mounting Plate so that the stop is uppermost (On the same side as the M13 Captive Nut).
8. Fix the Mounting Plate to the mounting surface using screw fixings suitable for both the type of mounting surface and the weight of the luminaire.
9. Make the mains/dimming connections to the Connector Block on the Mounting Plate according to the information on the label adjacent to the Connector Block.
10. Restrain the mains/dimming cable with the plastic Cable Clamp.
11. Loosen the knurled head of the suspension clutches (on the top of the luminaire) slightly, but do not completely remove.
12. Thread the suspension wires through the three holes in the mounting plate, one per hole.
13. Pass the suspension wire through the suspension clutch by pushing down on the knurled head. The clutch will re-engage when the knurled head is released which will support the luminaire temporarily.
14. Set the luminaire to the required height and check using a spirit level.
15. Finger tighten the knurled head of the suspension clutch.
16. Slide the cable gland removed earlier over the luminaire mains/dimming cable with the thread uppermost.
17. Pass the luminaire mains/dimming cable through the hole in the centre of the mounting plate cover and cut to the required length, allowing for a small amount of cable in the mounting plate.
18. Pass the luminaire mains/dimming cable through the M10 Captive Nut in the mounting plate and make the mains/dimming connections to the connector block according to the information on the label adjacent to the connector block.
19. Offer the mounting plate cover up to the mounting plate and reconnect the earth cable to the earth tab.
20. Fit the mounting plate cover to the mounting plate by screwing the cable gland into the M10 Captive Nut and secure the mains/dimming cable with the screw in the side of the cable gland.
21. Re-check that the luminaire is level and cut any excess suspension wire.
22. Reconnect the electrical supply and test the installation.