

IMPORTANT INFORMATION

SkyMod® Wafer Grid IM1189 SkyMod® Wafer Linear Grid IM1589



1. **NB:** Ensure electrical supply is isolated before fitting and/or making any electrical connections. Luminaires should be disconnected from the mains supply before any High Voltage Insulation tests are carried out.
2. Plug the Driver lead (already fitted) into the Panel lead by ensuring the polarity is correct by matching the arrows on the plug/socket.
3. Remove the ceiling tile in required position.
4. Feed the Mains/Dimming cable through the aperture.
5. Make the Mains/Dimming connections according to the information on the Driver.
6. Angle the Panel through the aperture and drop it down so that the panel is sitting securely on the T-Bars.
7. Alternatively wiring can be carried out by removing an adjacent tile after the Panel has been fitted.
8. Reconnect the electrical supply and test the installation.

Emergency Versions

1. Make a 20mm diameter hole in an adjacent tile for the Indicator Holder and push it into the tile.
2. Make the Mains/Dimming connections according to the information on the Driver.
3. Plug the Battery into the Driver, this connection should be made only when a permanent mains supply is in place.
4. Fit the Emergency Indicator into the white Indicator Holder.
5. Reconnect the electrical supply and test the installation.