Azuma[®] Maxi Solo/Duet

WL479/WL480/WL481/WL482



- **1. NB:** Ensure electrical supply is isolated before fitting and/or making any electrical connections. Luminaires should be disconnected from the mains supply before any High Voltage Insulation tests are carried out.
- 2. Make provision for fixing holes with centres of 50mm (other fixing hole positions are available).
- **3.** *NB:* The Azuma Maxi Solo can be positioned for either uplighting or downlighting.
- 4. Make an access hole for the mains/dimming cabling in the centre of the fixing holes (other cable entry holes are available).
- 5. Bring the mains/dimming cabling through the access hole allowing enough cable to reach the Connector Block.
- 6. Remove the two M4 Screws holding the Mounting Plate to the Gear Housing, remove the Mounting Plate and retain the Screws.
- 7. Disconnect the Earth Cable from the Earth Tab on the Mounting Plate.
- 8. Fix the Mounting Plate to the mounting surface using screw fixings suitable for both the type of mounting surface and the weight of the luminaire.
- 9. Offer the luminaire up to the Mounting Plate.
- 10. Make the mains/dimming connections to the Connector Block according to the information on the Mounting Plate.
- **11.** Re-connect the Earth Cable to the Earth Tab.
- **12.** Align the holes on the Gear Housing with the holes in the Mounting Plate and fix using the two M4 Screws previously removed.
- **13.** Reconnect the electrical supply and test the installation.



THE SILVERLINK, WALLSEND, NEWCASTLE UPON TYNE, TYNE & WEAR, NE28 9ND