

Emergency Battery Replacement
















connections are made prior to a permanent

mains supply being present and this is maintained for a minimum 24hrs to ensure correct operation.

4







IMPORTANT INFORMATION

Wallwasher Micro/Midi/Maxi

ID1629 / ID1631 / IM292



Disconnect electricity supply before installation

To be installed by qualified personnel only, in accordance with current building and wiring regulations.

When installing, we recommend wearing disposable gloves to avoid fingerprinting to the paint work of the luminaire.

Read leaflet fully before installation.




THE SILVERLINK, WALLSEND, NEWCASTLE UPON TYNE,
TYNE & WEAR, NE28 9ND

Technical: (0191) 280 9914
Email: technical@hacel.co.uk
Web: www.hacel.co.uk

01/2024 - V1

Preparation







Micro 167 x 85mm / **Midi** 308 x 85mm / **Maxi** 585 x 85mm

Disconnect electricity supply before installation











Wiring - Emergency Version






 For Emergency versions ensure the battery plug connections are made prior to a permanent mains supply being present and this is maintained for a minimum 24hrs to ensure correct operation.











Installation





2



3

